

# Bulk Inks

## 1L / 20L

PIGMENT: NEW PRODUCTS: **MODEL**

### HP / SAMSUNG

InkTec	OEM Cartridge
<b>H0001-01LB/ 20LB</b>	HP 15(c6615a/d), 20(c6614a/d), 29(51629a/g), 40(51640a), 45(51645a/g)
<b>H0002-01LC/ 20LC</b>	HP 17(c6625a/d), 23(c1823d/g), 41(51641a), 78(c6578a/ d), 78+(cb2777an)
<b>H0002-01LY/ 20LY</b>	
<b>H0004-01LC/ 20LC</b>	HP 10(c4841a), 11(c4836a), 13(c4815a)
<b>H0004-01LM/ 20LM</b>	HP 10(c4843a), 11(c4837a), 13(c4816a)
<b>H0004-01LY/ 20LY</b>	HP 10(c4842a), 11(c4838a), 13(c4817a)
<b>H0005-01LB/ 20LB</b>	HP 21(c9351a), 21(c9351g), 21XL(c9351c), 27(c8727a), 27b(c8727b), 56(c6656a), 702(cc660aa), 816(c8816a), 816b(c8816b) Samsung M75/ M80/ M90
<b>HC0005-01LB/ 20LB</b>	HP 21(c9351a), 21(c9351g), 21XL(c9351c), 27(c8727a), 27b(c8727b), 56(c6656a), 816b(c8816b), 816(c8816a), 816b(c8816b), 60/300/121/ 818(cc640wm), 60XL/ 300XL/ 121XL/ 818XL(cc641wm), 901(cc653a)/ 901XL(cc654a)
<b>H0006-01LC/ 20LC</b>	HP 22(c9352a), 22(c9352g), 22XL(c9352c), 28(c8728a), 49(51649a), 57(c6657a), 57+(cb278an), 81(c6817a), Samsung C75/ C80/ C90
<b>H0006-01LM/ 20LM</b>	
<b>H0006-01LY/ 20LY</b>	
<b>H1061-01LB/ 20LB</b>	HP 61/ 301/ 122/ 802(CH561WA) 61XL/ 301XL/ 122XL/ 802XL(CH563WA) 46/ 61/ 62/ 63/ 301/ 122/ 678/ 680/ 802(CH561WA) Samsung M170/ M180/ M260, LG 24
<b>H1061-01LC/ 20LC</b>	HP 61/ 301/ 122/ 802(CH562WA)
<b>H1061-01LM/ 20LM</b>	61XL/ 301XL/ 122XL/ 802XL(CH564WA)
<b>H1061-01LY/ 20LY</b>	46/ 61/ 62/ 63/ 301/ 122/ 678/ 680/ 802(CH561WA) Samsung C170/ C180/ C260, LG 25
<b>H2040-01LB/ 20LB</b>	HP 10(c4840a), 10(c4844a), 13(c4814a)
<b>H3070-01LB/ 20LB</b>	HP 02/ 363/ 177/ 801 (c8721) 02XL(c8719)/ 363XL(c8719)/ 177XL(c8719)/ 801XL(c8721)
<b>H3070-01LC/ 20LC</b>	HP 02/ 363/ 177/ 801(c8771)/ 02XL(c8730)
<b>H3070-01LM/ 20LM</b>	HP 02/ 363/ 177/ 801(c8772)/ 02XL(c8731)
<b>H3070-01LY/ 20LY</b>	HP 02/ 363/ 177/ 801(c8773)/ 02XL(c8732)
<b>H3070-01LLC/ 20LLC</b>	HP 02/ 363/ 177/ 801(c8774)/ 02XL(c8733)
<b>H3070-01LLM/ 20LLM</b>	HP 02/ 363/ 177/ 801(c8775)/ 02XL(c8734)
<b>H4060-01LB/ 20LB</b>	HP 60/ 300/ 121/ 818(cc640wm), 80XL/ 300XL/ 121XL/ 818XL(cc641wm), 901(cc653a)/ 901XL(cc654a), 60/ 300/ 121/ 703/ 818 (cc640wm) Samsung M160
<b>H4060-01LC/ 20LC</b>	HP 60/ 300/ 121/ 818(cc643wm)
<b>H4060-01LM/ 20LM</b>	60XL/ 300XL/ 121XL/ 818XL(cc644wm)
<b>H4060-01LY/ 20LY</b>	901(cc656a)/ 60/ 300/ 121/ 703/ 818 (cc643wm) Samsung C160
<b>H5088-01LB/ 20LB</b>	HP 18(c4936a), 88(c9385a)/ 88XL(c9396a), 940(c4902an/e)/ 940XL(c4906an/e)/ 942XL(cn016aa), 950(cn049an)/ 950XL(cn045an), 932(cn057an)/ 932XL(cn053an), 970(CN621A)/ 970XL(CN625A) 971XL(CN628A)/ 711/ 903

InkTec	OEM Cartridge
<b>H5088-01LC/ 20LC</b>	HP 18(c4937a), 88(c9386a)/ 88XL(c9391a)
<b>H5088-01LM/ 20LM</b>	HP 18(c4938a), 88(c9387a)/ 88XL(c9392a)
<b>H5088-01LY/ 20LY</b>	HP 18(c4939a), 88(c9388a)/ 88XL(c9393a)
<b>H5851-01LB/ 20LB</b>	HP GT51(MOH57AA)
<b>H5852-01LC/ 20LC</b>	HP GT52(MOH54AA)
<b>H5852-01LM/ 20LM</b>	HP GT52(MOH55AA)
<b>H5852-01LY/ 20LY</b>	HP GT52(MOH56AA)
<b>H5970-01LB/ 20LB</b>	HP 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993
<b>H5971-01LC/ 20LC</b>	HP 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993
<b>H5971-01LM/ 20LM</b>	HP 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993
<b>H5971-01LY/ 20LY</b>	HP 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993
<b>H6065-01LB/ 20LB</b>	HP 92/ 336/ 850/ 1326(9362), 94/ 338/ 131/ 852(c8765), 96/ 339/ 130/ 853(c8767), 98/ 337/ 129/ 851(c9364), 74/ 140/ 350/ 860(cb335), 74XL/ 140XL/ 350XL/ 860XL(cb336) Samsung M95/ M110/ M115/ M120
<b>H6066-01LC/ 20LC</b>	HP 93/ 342/ 854/ 136(c9361),
<b>H6066-01LM/ 20LM</b>	95/ 343/ 135/ 856(c8766), 97/ 344/ 134/ 85(c9363), 97/ 344/ 134/ 85(c9363), 75/ 141/ 351/ 861(cb337), 75XL/ 141XL/ 351XL/ 861XL(cb338), 110(cb304) Samsung C95/ C100/ C110
<b>H6066-01LY/ 20LY</b>	
<b>H7064-01LB/ 20LB</b>	HP 564/ 364/ 178/ 862(cb316) 564XL/ 364XL/ 178XL/ 862XL(cb321) 920(cd971an)/ 920XL(cd975an)/ 922(cn025)/ 922XL(cn026)/ 364/ 564/ 685/ 178/ 862(cb316) Samsung K200
<b>H7064-01LPB/ 20LPB</b>	HP 364/ 564/ 178/ 862(cb317) 364XL/ 564XL/ 178XL/ 862XL(cb322)
<b>H7064-01LC/ 20LC</b>	HP 364/ 564/ 178/ 862(cb318) 364XL/ 564XL/ 178XL/ 862XL(cb323) 920(ch634an)/ 920XL/ 922XL(cd972an) 364/ 564/ 685/ 178/ 862(cb318) Samsung C200
<b>H7064-01LM/ 20LM</b>	HP 364/ 564/ 178/ 862(cb319) 364XL/ 564XL/ 178XL/ 862XL(cb324) 920(ch635an)/ 920XL/ 922XL(cd973an) 364/ 564/ 685/ 178/ 862(cb319) Samsung M200
<b>H7064-01LY/ 20LY</b>	HP 364/ 564/ 178/ 862(cb320) 364XL/ 564XL/ 178XL/ 862XL(cb325) 920(ch636an)/ 920XL/ 922XL(cd974an) 364/ 564/ 685/ 178/ 862(cb320) Samsung Y200

### HP / SAMSUNG

InkTec	OEM Cartridge
<b>H8940-01LC/ 20LC</b>	HP 940(c4903an/e)/ 940XL(c4907an/e)/ 942XL(cn017aa), 951(cn050an)/ 951XL(cn046an), 933(cn058an)/ 933XL(cn054an), 971(CN622A)/ 971XL(CN626A)
<b>H8940-01LM/ 20LM</b>	HP 940(c4904an/e)/ 940XL(c4908an/e)/ 942XL(cn018aa), 951(cn051an)/ 951XL(cn047an), 933(cn059an)/ 933XL(cn055an), 971(CN623A)/ 971XL(CN627A)
<b>H8940-01LY/ 20LY</b>	HP 940(c4905an/e)/ 940XL(c4909an/e)/ 942XL(cn019aa), 951(cn052an)/ 951XL(cn048an), 933(cn060an)/ 933XL(cn056an), 971(CN624A)/ 971XL(CN628A)
<b>H8950D-01LB/ 20LB</b>	HP 940(C4902AN/E)/940XL(C4906AN/E), 942XL(CN016AA), 950(CN049AN)/ 950XL(CN045AN), 970(CN621AM)/ 970XL(CN625AM), 932(CN057AN)/ 932XL(CN053AN), 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993/ LG 327(LIP3270S3C) 327(LIP3270S3C)
<b>H8950D-01LC/ 20LC</b>	HP 940(c4903an/e)/ 940XL(c4907an/e)/ 942XL(cn017aa), 951(cn050an)/ 951XL(cn046an), 933(cn058an)/ 933XL(cn054an), 971(CN622A)/ 971XL(CN626A), 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993/ LG 327(LIP3270S3C) 327(LIP3270S3C)
<b>H8950D-01LM/ 20LM</b>	HP 940(c4904an/e)/ 940XL(c4908an/e)/ 942XL(cn018aa), 951(cn051an)/ 951XL(cn047an), 933(cn059an)/ 933XL(cn055an), 971(CN623A)/ 971XL(CN627A)/ 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993/ LG 327(LIP3270S3M), 27(LIP3270S3C)
<b>H8950D-01LY/ 20LY</b>	HP 940(c4905an/e)/ 940XL(c4909an/e)/ 942XL(cn019aa), 951(cn052an)/ 951XL(cn048an), 933(cn060an)/ 933XL(cn056an), 971(CN624A)/ 971XL(CN628A)/ 711/ 903/ 952/ 952XL/ 953/ 953XL/ 954/ 954XL/ 955/ 955XL/ 972/ 973/ 975/ 993/ LG 327(LIP3270S3Y) 327(LIP3270S3C)

### EPSON

InkTec	OEM Cartridge
<b>E0013-01LC/ 20LC</b>	T0712##, T0732##, T0732N##, T0882##, T0892##, T0912##, T0922##, T0922N##, T1002, T1032, T1282##, T1292##, T1302##, T1332##, T1352##, T1402##, T1412##, T1422##, T1432##, T6762/ T6772/ T6782/ T012/ T022/ T032/ T712, T2002/ T200XL2
<b>E0013-01LM/ 20LM</b>	T0713##, T0733##, T0733N##, T0883##, T0893##, T0913##, T0923##, T0923N##, T1003, T1033, T1283##, T1293##, T1303##, T1333##, T1353##, T1403##, T1413##, T1423##, T1433## T6763/ T6773/ T6783/ T013/ T023/ T033/ T713, T2003/ T200XL3
<b>E0013-01LY/ 20LY</b>	T0714##, T0734##, T0734N##, T0884##, T0894##, T0914##, T0924##, T0924N##, T1004, T1034, T1284##, T1294##, T1304##, T1334##, T1354##, T1404##, T1414##, T1424##, T1434## T6764/ T6774/ T6784/ T014/ T024/ T034/ T714, T2004/ T200XL4

### EPSON

InkTec	OEM Cartridge
<b>E0014-01LB/ 20LB</b>	T2421/ T2431/ T2561/ T2611/ T2631/ T2691/ T2731/ T273XL1/ T2771/ T277XL1/ T3781
<b>E0014-01LC/ 20LC</b>	T2422/ T2432/ T2562/ T2612/ T2632/ T2692/ T2732/ T273XL2/ T2772/ T277XL2/ T3782
<b>E0014-01LM/ 20LM</b>	T2423/ T2433/ T2563/ T2613/ T2633/ T2693/ T2733/ T273XL3/ T2773/ T277XL3/ T3783
<b>E0014-01LY/ 20LY</b>	T2424/ T2434/ T2564/ T2614/ T2634/ T2694/ T2734/ T273XL4/ T2774/ T277XL4/ T3784
<b>E0014-01LLC/ 20LLC</b>	T2425/ T2435/ T2775/ T277XL5/ T3785/ T3786
<b>E0014-01LLM/ 20LLM</b>	T2426/ T2436/ T2776/ T277XL6
<b>E0015-01LB/ 20LB</b>	T2551/ T2601/ T2621/ T2690/ T2730/ T273XL0
<b>E10034-01LPB/ 20LPB</b>	T0341##
<b>E10034-01LC/ 20LC</b>	T0342##
<b>E10034-01LM/ 20LM</b>	T0343##
<b>E10034-01LY/ 20LY</b>	T0344##
<b>E10034-01LLC/ 20LLC</b>	T0345##
<b>E10034-01LLM/ 20LLM</b>	T0346##
<b>E10034-01LLB/ 20LLB</b>	T0347##
<b>E10034-01LMB/ 20LMB</b>	T0348##
<b>E10054-01LMB/ 20LMB</b>	T0548##
<b>E0004-01LB/ 20LB</b>	T0321##, T0431##, T0441##, T0461##
<b>E0004-01LC/ 20LC</b>	T0322##, T0422##, T0442##, T0472##
<b>E0004-01LM/ 20LM</b>	T0323##, T0423##, T0443##, T0473##
<b>E0004-01LY/ 20LY</b>	T0324##, T0424##, T0444##, T0474##
<b>E0005-01LB/ 20LB</b>	T0481##, T0491## S020093, S020108, S020138, S020187, S020189, S187093, S189108 T03###, T007###, T013###, T017### T019###, T026###, T028###, T0321### T0331##, T036###, T038###, T040### T050###, T051###, T0751##, T0761##
<b>E0005-01LC/ 20LC</b>	T0482##, T0492## S020089, S020110, S020138, S020191 S020193, S191089, S193110 T01###, T008###, T009###, T014###, T018###, T020###, T027###, T029###, T0333###, T037###, T039###, T041###, T052###, T053###, T0753###, T0763##, T0323##, T0423##
<b>E0005-01LM/ 20LM</b>	T0483##, T0493## S020089, S020110, S020138, S020191 S020193, S191089, S193110 T01###, T008###, T009###, T014###, T018###, T020###, T027###, T029###, T0333###, T037###, T039###, T041###, T052###, T053###, T0753###, T0763##, T0323##, T0423##
<b>E0005-01LY/ 20LY</b>	T0484##, T0494## S020089, S020110, S020138, S020191 S020193, S191089, S193110 T01###, T008###, T009###, T014###, T018###, T020###, T027###, T029###, T0333###, T037###, T039###, T041###, T052###, T053###, T0753###, T0763##, T0323##, T0423##
<b>E0005-01LLC/ 20LLC</b>	T0485##, T0495## S193110, S020110, S020193 T01###, T008###, T009###, T027### T0335##, T053##
<b>E0005-01LLM/ 20LLM</b>	T0486##, T0496## S193110, S020110, S020193 T01###, T008###, T009###, T027### T0336##, T053###

EPSON

InkTec	OEM Cartridge
● E0007-01LB/20LB	T0601##, T0611##, T0621##, T0631##
● E0007-01LC/20LC	T0602##, T0612##, T0632##
● E0007-01LM/20LM	T0603##, T0613##, T0633##
● E0007-01LY/20LY	T0604##, T0614##, T0634##
● E0010-01LB/20LB	T0771##, T0781##, T0791##, T0801##, T0811##, T0821##, T0851##, T0811N##, T0821N##, T6641/ T6721, T6761/ T6771/ T6781/ T7011/ T7021/ T7031/ T7111, For EPSON DISCPRODUCER INK
● E0010-01LC/20LC	T0772##, T0782##, T0792##, T0802##, T0812##, T0822##, T0852##, T0812N##, T0822N##, T6642/ T6722, T6762/ T6772/ T6782/ T7012/ T7022/ T7032/ T7112/ T702/ T712/ T1762/ T1772/ T1802/ T1812, For EPSON DISCPRODUCER INK
● E0010-01LM/20LM	T0773##, T0783##, T0793##, T0803##, T0813##, T0823##, T0853##, T0813N##, T0823N##, T6643/ T6723/ T6763/ T6773/ T6783/ T7013/ T7023/ T7033/ T7113/ T1703/ T1713/ T1763/ T1773/ T1803/ T1813, For EPSON DISCPRODUCER INK
● E0010-01LY/20LY	T0774##, T0784##, T0794##, T0804##, T0814##, T0824##, T0854##, T0814N##, T0824N##, T6644/ T6724, T6764/ T6774/ T6784/ T7014/ T7024/ T7034/ T7114, T1704/ T1714/ T1764/ T1774/ T1804/ T1814, For EPSON DISCPRODUCER INK
● E0010-01LM/20LLC	T6735/ T6745
● E0010-01LY/20LLM	T0775##, T0785##, T0795##, T0805##, T0815##, T0825##, T0855##, T0815N##, T0825N##
● E0011-01LB/20LB	T0681##, T0691##, T0711##, T0731##, T0731N##, T0881##, T0891##, T0901##, T0911##, T0921##, T0921N##, T0911N##, T1001, T1031
● E0011-01LC/20LC	T0682##, T0692##, T0712##, T0732##, T0732N##, T0882##, T0892##, T0912##, T0922##, T0922N##, T1002, T1032
● E0011-01LM/20LM	T0683##, T0693##, T0713##, T0733##, T0733N##, T0883##, T0893##, T0913##, T0923##, T0923N##, T1003, T1033
● E0011-01LY/20LY	T0684##, T0694##, T0714##, T0734##, T0734N##, T0884##, T0894##, T0914##, T0924##, T0924N##, T1004, T1034
● E0013-01LB/20LB	T0711##, T0731##, T0731N##, T0881##, T0891##, T0901##, T0911##, T0921##, T0921N##, T0971##, T1151##, T1171##, T1001, T1031, T1301##, T1331##, T1351##, T1401##, T1411##, T1421##, T1431##, T6761/ T6771/ T6781/ T7011/ T7021/ T7031/ T7111, T1701/ T1711/ T1761/ T1771/ T1781/ T1801/ T1811/ T2001/ T200XL1, T7741

InkTec	OEM Cartridge
● E0014-01LB/20LB	T2421/ T2431/ T2561/ T2611/ T2631/ T2691/ T2731/ T273XL1/ T2771/ T277XL1
● E0014-01LC/20LC	T2422/ T2432/ T2562/ T2612/ T2632/ T2692/ T2732/ T273XL2/ T2772/ T277XL2
● E0014-01LM/20LM	T2423/ T2433/ T2563/ T2613/ T2633/ T2693/ T2733/ T273XL3/ T2773/ T277XL3
● E0014-01LY/20LY	T2424/ T2434/ T2564/ T2614/ T2634/ T2694/ T2734/ T273XL4/ T2774/ T277XL4
● E0014-01LLC/20LLC	T2425/ T2435/ T2775/ T277XL5
● E0014-01LLM/20LLM	T2426/ T2436/ T2776/ T277XL6
● E0015-01LB/20LB	T2551/ T2601/ T2621/ T2690/ T2730/ T273XL0
● E10034-01LPB/20LPB	T0341##
● E10034-01LC/20LC	T0342##
● E10034-01LM/20LM	T0343##
● E10034-01LY/20LY	T0344##
● E10034-01LLC/20LLC	T0345##
● E10034-01LLM/20LLM	T0346##
● E10034-01LLB/20LLB	T0347##
● E10034-01LMB/20LMB	T0348##
● E10054-01LMB/20LMB	T0548##
● E0017-01LB/20LB	T6731/ T6741
● E0017-01LC/20LC	T6732/ T6742
● E0017-01LM/20LM	T6733/ T6743
● E0017-01LY/20LY	T6734/ T6744
● E0017-01LLC/20LLC	T6735/ T6745
● E0017-01LLM/20LLM	T6736/ T6746

RICOH

InkTec	OEM Cartridge
● R0001-01LC/20LC	RC-1CS1/ RC-1C01/ RC-1C11, GC21CS/ GC21C/ GC21CH, GC31CS/ GC31C/ GC31CH, GC41CS/ GC41C/ GC41CH
● R0001-01LM/20LM	RC-1MS1/ RC-1M01/ RC-1M11, GC21MS/ GC21M/ GC21MH
● R0001-01LY/20LY	RC-1YS1/ RC-1Y01/ RC-1Y11, GC21YS/ GC21Y/ GC21YH, GC31YS/ GC31Y/ GC31YH, GC41YS/ GC41Y/ GC41YH
● R0002-01LB/20LB	RC-1KS1/ RC-1K01/ RC-1K11, GC21KS/ GC21K/ GC21KH, GC31KS/ GC31K/ GC31KH, GC41KS/ GC41K/ GC41KH
● R0002-01LM/20LM	GC31MS/ GC31M/ GC31MH, GC41MS/ GC41M/ GC41MH

CLEANING SOLUTION

InkTec	For use with
● TCS-01LP/20LP	The cartridges for all thermal type printers
● MCS-01LP/20LDP	The cartridges for all thermal & piezo type printers

CANON

InkTec	OEM Cartridge
● C0090-01LB/20LB	GI-490/590/790/890/990
● C0090-01LC/20LC	GI-490/590/790/890/990
● C0090-01LM/20LM	GI-490/590/790/890/990
● C0090-01LY/20LY	GI-490/590/790/890/990
● C905-01LB/20LB	PGI-5BK, PG-30/ 37/ 40/ 50/ 830
● C908-01LB/20LB	CLI-8BK, CL-52
● C908-01LC/20LC	CLI-8C/ 8M/ 8Y
● C908-01LM/20LM	CL-31/ 38/ 41/ 51/ 831
● C908-01LY/20LY	
● C908-01LLC/20LLC	CLI-8PC/ 8PM, CL-52
● C908-01LLM/20LLM	
● C2010-01LB/20LB	PG-210/ 810/ 510, PG-210XL/ 810XL/ 512/ 49
● C2011-01LC/20LC	CL-211/ 811/ 511
● C2011-01LM/20LM	CL-211XL/ 811XL/ 513
● C2011-01LY/20LY	CL-59
● C5000-01LB/20LB	PGI-1200/1200XL/1300/1300XL/1400XL/1500XL/ 1600/1600XL/1700/1700XL/1800/1800XL/1900/ 1900XL/2200/2200 XL/2300/2300XL/2400XL/ 2500XL/2600/2600XL/2700/2700XL/2800/ 2800XL/2900XL
● C5000D-01LC/20LC	PGI-1200/1200XL/1300/1300XL/1400XL/1500XL/ 1600/1600XL/1700/1700XL/1800/1800XL/1900/ 1900XL/2200/2200 XL/2300/2300XL/2400XL/ 2500XL/2600/2600XL/2700/2700XL/2800/ 2800XL/2900XL
● C5000D-01LM/20LM	1600/1600XL/1700/1700XL/1800/1800XL/1900/ 1900XL/2200/2200 XL/2300/2300XL/2400XL/ 2500XL/2600/2600XL/2700/2700XL/2800/ 2800XL/2900XL
● C5000D-01LY/20LY	
● C5025-01LB/20LB	PGI-225BK/ 425BK/ 525BK/ 725BK
● C5026-01LB/20LB	CLI-226BK/ 426BK/ 526BK/ 726BK
● C5026-01LC/20LC	CLI-226C/ 426C/ 526C/ 726C
● C5026-01LM/20LM	CLI-226M/ 426M/ 526M/ 726M
● C5026-01LY/20LY	CLI-226Y/ 426Y/ 526Y/ 726Y
● C5040-01LB/20LB	PG-240/ 440/ 540/ 640/ 740
	PG-240XL/ 440XL/ 540XL/ 640XL/ 740XL
	PG-64/ 83/ 88
● C5041-01LC/20LC	CL-241/ 441/ 541/ 641/ 741
● C5041-01LM/20LM	CL-241XL/ 441XL/ 541XL/ 641XL/ 741XL
● C5041-01LY/20LY	CL-74/ 93/ 98
● C5050-01LB/20LB	PGI-250PGBK/ 250XLPGBK/ 450PGBK/ 450XLPGBK/ 455XLPGBK/ 550PGBK/ 550XLPGBK/ 555XLPGBK/ 650PGBK/ 650XLPGBK/ 750PGBK/ 750XLPGBK/ 850PGBK/ 850XLPGBK/ 855XLPGBK
	PG-245/ 245XL/ 445/ 445XL/ 545/ 545XL/ 645/ 645XL/ 845/ 845XL/ 945/ 945XL
	646XL/ 846/ 846XL/ 946/ 946XL
	570PGBK/ 570XLPGBK/ 970PGBK/ 970XLPGBK
● C5051-01LB/20LB	CLI-251BK/ 251XLBK/ 451BK/ 451XLBK/ 551BK/ 551XLBK/ 651BK/ 651XLBK/ 751BK/ 751XLBK/ 851BK/ 851XLBK/ 517BK/ 517XLBK/ 917BK/ 917XLBK

InkTec	OEM Cartridge
● C5051-01LC/20LC	CLI-251C/ 251XLC/ 451C/ 451XLC/ 551C/ 551XLC/ 651C/ 651XLC/ 751C/ 751XLC/ 851C/ 851XLC
	CL-246/ 246XL/ 446/ 446XL/ 546/ 546XL/ 646/ 646XL/ 846/ 846XL/ 946/ 946XL
	571C/ 571XLC/ 571C/ 971XLC
● C5051-01LM/20LM	CLI-251M/ 251XLM/ 451M/ 451XLM/ 551M/ 551XLM/ 651M/ 651XLM/ 751M/ 751XLM/ 851M/ 851XLM, CL-246/ 246XL/ 446/ 446XL/ 546/ 546XL/ 646/ 646XL/ 846/ 846XL/ 946/ 946XL
	571M/ 571XLM/ 571M/ 971XLM
● C5051-01LY/20LY	CLI-251Y/ 251XLY/ 451Y/ 451XLY/ 551Y/ 551XLY/ 651Y/ 651XLY/ 751Y/ 751XLY/ 851Y/ 851XLY
	CL-246/ 246XL/ 446/ 446XL/ 546/ 546XL/ 646/ 646XL/ 846/ 846XL/ 946/ 946XL
	571Y/ 571XLY/ 571Y/ 971XLY
● C9020-01LB/20LB	PGI-220BK/ 820BK/ 520BK, BCI-320BK
● C9021-01LB/20LB	CLI-221BK/ 821BK/ 521BK, CBI-321BK
● C9021-01LC/20LC	CLI-221C/ 821C/ 521C, CBI-321C
● C9021-01LM/20LM	CLI-221M/ 821M/ 521M, CBI-321M
● C9021-01LY/20LY	CLI-221Y/ 821Y/ 521Y, CBI-321Y

BROTHER

InkTec	OEM Cartridge
● B1100-01LB/20LB	LC12BK/ LC17BK/ LC39BK/ LC39BK/ LC61BK/ LC65BK/ LC65HYBK/ LC67BK/ LC71BK/ LC73BK/ LC75BK/ LC77BK/ LC79BK/ LC400BK/ LC450BK/ LC390BK/ LC395BK/ LC1100BK/ LC1100HYBK/ LC1220BK/ LC1240BK/ LC1280BK/ LC101BK/ LC103BK/ LC107BK/ LC109BK/ LC121BK/ LC123BK/ LC127XLBK/ LC133BK/ LC137XLBK/ LC563BK/ LC567XLBK/ LC529XLBK/ LC539XLBK
● B1100-01LC/20LC	LC12C/ LC17C/ LC39C/ LC39C/ LC61C/ LC65C/ LC65HYC/ LC67C/ LC71C/ LC73C/ LC75C/ LC77C/ LC79C/ LC400C/ LC450C/ LC390C/ LC395C/ LC1100C/ LC1100HYC/ LC1220C/ LC1240C/ LC1280C/ LC101C/ LC103C/ LC105C/ LC121C/ LC123C/ LC125XLC/ LC133C/ LC135XLC/ LC563C/ LC565XLC/ LC525XLC/ LC535XLC
● B1100-01LM/20LM	LC12M/ LC17M/ LC39M/ LC39M/ LC61M/ LC65M/ LC65HYM/ LC67M/ LC71M/ LC73M/ LC75M/ LC77M/ LC79M/ LC400M/ LC450M/ LC390M/ LC395M/ LC1100M/ LC1100HYM/ LC1220M/ LC1240M/ LC1280M/ LC101M/ LC103M/ LC105M/ LC121M/ LC123M/ LC125XLM/ LC133M/ LC135XLM/ LC563M/ LC565XLM/ LC525XLM/ LC535XLM
● B1100-01LY/20LY	LC12Y/ LC17Y/ LC39Y/ LC39Y/ LC61Y/ LC65Y/ LC65HY/ LC67Y/ LC71Y/ LC73Y/ LC75Y/ LC77Y/ LC79Y/ LC400Y/ LC450Y/ LC390Y/ LC395Y/ LC1100Y/ LC1100HY/ LC1220Y/ LC1240Y/ LC1280Y/ LC101Y/ LC103Y/ LC105Y/ LC121Y/ LC123Y/ LC125XLY/ LC133Y/ LC135XLY/ LC563Y/ LC565XLY/ LC525XLY/ LC535XLY
● B6000-01LB/20LB	BT6000BK